



**TECHNICAL DATA**

Proscenium Opening	8 000mm - 11 200mm (w) x 7 180mm (h)
Setting Line to D/S of Rear Columns	10 000mm
Setting Line to Edge of Stage	800mm
Setting Line to Edge of Forestage/Pit Elevator	3110mm
Depth of Forestage/Pit Elevator	2 310mm
Height of Stage from Stalls Level	910mm
Max Width of Stage	20 750mm
Width Between Fly Floors	15 650mm
Clearance to Underside of Fly Floors	6700mm
Height to Underside of Grid (Bar Travel)	15 500mm
Bar Width Counter Weights	11 500mm SWL 400kg UDL / 45kg PL
Bar Width DP Counter Weights	12 000mm SWL 370kg UDL / 50kg PL
Bar Width Hemp Sets	10 650mm SWL 50kg UDL

  

Get In Clearance Dimensions	Stage Left	2 250 (w) x 6 300 (h)
	Stage Right	2 350 (w) x 2 800 (h)

**General Notes**

1. Checked and updated January 2012 (S. Macluskie)
2. Class & Layer re-structure March 2012 (S. Cook)
3. Substage Walk up trap added March 2012 (S. Cook)
4. Setting Line Changed to 800mm from Front of Stage
5. Tidied Up Auditorium Lines Dec 2012
6. Changed Setting & Centre Lines to "Guides"

**2013 Updates**

1. Added DSL & DSR Door Access
2. Changed Prosc. Wall L&R
3. Removed all extra symbol folders to reduce file size
4. Updated SWL of DP to 370kg
5. Added Setting Line to main Sheet Layers

Steve Macluskie 0141 270 8257  
Simon Cook 0141 270 8108

Right View of section (from S20/3/15)

Sir John in Love