

Stress Formula



$$L \times A = S$$

L = Load

A = Angle Factor

S = Stress in Kg

Angle	Factor
0°	2.00
40°	1.87
90°	1.41



T. Cass